

# FLOORING AFTERCARE MANUAL

# Aftercare Instructions for FLOORINGS

## **Vinyl, Laminate & Engineered Timber**

- DAILY cleaning with vacuum cleaner, broom, damp cloth or mop.
- ALWAYS remove excess water on floor IMMEDIATELY.
- Remove normal stains with NEUTRAL detergent.
- NO wet-washing.
- USE soft felt pads under furniture legs or chair legs to avoid scratches.
- USE a doormat in front of entrances to reduce the amount of dirt, grit and moisture.
- USE soft treads/rollers on rollers of office chairs and file trolleys.

## **Applicable to Vinyl only**

- DO NOT use rubber-backed or coco-fiber mats as they may cause yellow stains
- DO NOT expose to direct sunlight to avoid discoloration

## **Engineered Timber**

- DO NOT use steam cleaners.
- Damaged areas can be repaired by filling with a soft wax that matches the colour of the floor.
- Sanding of the floors can be done to completely renovate the engineered timber floor. Appropriate lacquer or oil products can be used for subsequent surface treatment.

## **Outdoor WPC Decking**

REGULAR water washing is recommended.

**Please request for a detailed maintenance guide from the salesperson once the project is confirmed, as it may differ depending on the brand.**